
Document shredders DAHLE 206





Document shredders DAHLE 206







Separate main switch is located on the rear of the Detachable IEC power plug makes the document Pull-out rounded top frame that's kind on the document shredder and completely disconnects it from the mains power supply



shredder quick and easy to move from A to B




fingers when changing the waste bag



Document shredders DAHLE 206



Separate, integrated waste boxes help to sort shredded paper, CDs, DVDs, cheque and credit cards for eco-friendly recycling



P-2 security: recommended, for example, for data media containing internal data that are to be made illegible

